



## Quick Pre-Check

### Before You Begin: Quick Pre-Check

---

#### Flash Control Unit (FCU)

- Power Switch: **LOCK**
- Display: **ETTL** (upper left corner)
- Red Indicator Light: **On**

#### Lens Settings:

- Focusing Distance: **Full**
- Focus Mode: **AF**
- Image Stabilizer: **On**

#### Camera Body:

- Top-Left Dial: Set to <img alt="camera icon" data-bbox="278 371 298 384"/> (still photo mode)
- Mode Dial: Set to **C1**
- Power Switch: **LOCK**

#### Aperture (Main Dial):

- **f/5.6** – Distant/low light
- **f/22** – Close-up/well-lit

#### AF Frame (Square):

- Ensure white square is centered
- Press **SET** (inside Quick Control Dial) to recenter if needed



## Washed-Out / Overexposed Photos


### Washed-Out / Overexposed Photos

---

Verify that the mounting foot is fully inserted into the camera's hot shoe.

- Insert the **mounting foot** fully into the camera's **hot shoe**.
- Slide the **mounting foot lock lever** to the right until it clicks into place.


*If the mounting foot is not securely inserted and locked, it may result in overexposed photos.*



Verify the Shooting Mode on the Flash Control Unit (FCU) is set to E TTL.

- If **M** appears in the top-left corner of the FCU's LCD panel, follow the steps below.
- Switch the power from **Lock** to **On**.
- Press the **Mode** button until the display shows **E TTL**.
- Switch the power back to **Lock**.

*Operating in **M mode** will result in overexposed photos.*



★For additional details, see **Page 3** in the **SDFI Quick Start Guide: VS - G12**.






## Yellow-Tinted Photos

### Yellow-Tinted Photos

This may indicate that the **Flash Control Unit (FCU) batteries** need to be replaced.

Replace **Flash Control Unit** Batteries:

- Open the **Battery Compartment**.
- Slide the **Lock-Release Lever** to the left, then slide the cover down to open it.
- Insert four AA batteries, matching the "+" and "-" ends to the image inside the compartment.
- Close the **Battery Compartment** by sliding the cover up until it clicks.



★For additional details, see **Page 2** in the **SDFI Quick Start Guide: VS - G12**.



## Blurry Photos

### Blurry Photos

---

The white **AF (autofocus) Frame** indicates the area where the camera will focus.

- Locate the white **AF Frame** (white square) on the screen.
- Verify the white **AF Frame** is centered on the area of interest.

*If your area of interest is centered but the AF (autofocus) frame appears in the upper right, the camera will focus on that upper right area—not the center.*

- Recenter the white **AF Frame**

*If it's not centered, press the **SET** button (inside the Quick Control Dial) to **return** it to the center of the screen.*



★For additional details, see **Page 4** in the **SDFI Quick Start Guide: VS - G12**.




## Missing the White AF (Autofocus) Frame

### Missing the White AF (Autofocus) Frame

---

- Switch the lens from **MF (Manual Focus)** to **AF (Auto Focus)**.  
*The lens settings switch is located on the left side of the camera lens.*



★For additional details, see **Page 2** in the **SDFI Quick Start Guide: VS - G12**.




## Error Codes & Solutions: Error Code F00

### Error Codes & Solutions

---

- **Error Code F00** → The lens is not securely attached.
  - Turn the lens clockwise until you hear a click.








## Error Codes & Solutions: Error Code 01

### Error Codes & Solutions

- **Error Code 01** → Communication issue between camera and lens.
  - Remove the **Macro Ring Lite MR-14EX II** from the camera lens by pressing the “**TOP**” Button on top of the **Ring Lite**.



- Locate the lens **release button** on the Left side of the camera body, near the lens settings.
- Press it and rotate the lens counterclockwise to remove it.



- Gently clean the metal contact area around the lens and camera body using a soft, dry cloth.






## Error Codes & Solutions: Error Code 01 – Continued


### Error Codes & Solutions

---



- Reattach the lens by aligning the two red markings on both the lens and camera body, then rotate clockwise until it locks securely in place.



- Turn the camera's **power switch** to the **LOCK** position and verify if the error has been resolved.



- If the issue is fixed, reattach the **Macro Ring Lite MR-14EX II** by pressing the **TOP** button on the **Macro Ring Lite MR-14EX II** and carefully placing it back onto the camera lens.





## Additional Helpful Tips

### Flash Control Unit Battery Recommendations

---

- Alkaline
- NiCd
- Lithium
- Ni-MH


### SDFI SD Card - Best Performance, Reliability and Compatibility.

---

- High-Speed Data Transfer – Using a **SDFI SD Card** transfers at 300 MB/s, making it 3.5 to 4 times faster than an average SD card (80 MB/s) for quicker saving, loading, and transferring of images.
- 32GB Storage Capacity – Provides ample space for high-resolution images.
- Durable & Impact-Resistant – Built to withstand harsh conditions, for example, running through a wash cycle.



## Part Names – Front of Camera




- (1) ★ Mode dial
- (2) ★ < OFF / LOCK / ON > Power/multi-function lock switch
- (3) ★ <  > Main dial
- (4) < M-Fn > Multi-function button
- (5) ★ Shutter button
- (6) Movie shooting button
- (7) Self-timer lamp/AF-assist beam
- (8) Grip (battery compartment)
- (9) DC cord hole
- (10) Depth-of-field preview button
- (11) Contacts
- (12) Lens mount
- (13) Shoe cover
- (14) Flash sync contacts
- (15) ★ Multi-function shoe / Hot Shoe
- (16) RF lens mount index
- (17) ★ <  > Still photo shooting/movie recording switch
- (18) Strap mount
- (19) <  > Focal plane mark
- (20) Microphone
- (21) Image sensor
- (22) ★ Lens release button
- (23) Lens lock pin
- (24) ★ Body cap

★ Commonly used features.



## Part Names – Back of Camera




- (1) Eyecup
- (2) ★ Viewfinder eyepiece
- (3) < MENU > Menu button
- (4) Terminal cover
- (5) < AF-ON > AF start button
- (6) <  > Quick control dial 2
- (7) <  > Multi-controller (can also be pressed straight in)
- (8) ★ < Q > Magnify/reduce button
- (9) <  > Quick Control button
- (10) ★ <  > Quick control dial 1
- (11) ★ <  > Set button
- (12) ★ <  > Playback button
- (13) < INFO > Info button
- (14) ★ Viewfinder sensor
- (15) < RATE > Rating button
- (16) < MIC > External microphone IN terminal
- (17) <  > Digital terminal
- (18) <  > Headphone terminal
- (19) ★ < HDMI OUT > HDMI micro OUT terminal
- (20) ★ <  > Remote control terminal

★ Commonly used features.



## Part Names – Right Side of Camera



- (1) Dioptic adjustment knob
- (2) Accessory positioning hole
- (3) ★ Screen
- (4) Tripod socket
- (5) Serial number (body number)
- (6) <  > Erase button
- (7) Speaker
- (8) <  > AE lock button
- (9) <  > AF point selection button
- (10) Strap mount
- (11) Access lamp
- (12) Card slot cover
- (13)★ Card slot 2
- (14)★ Card slot 1
- (15)★ Battery compartment cover lock
- (16)★ Battery compartment cover
- (17) Accessory positioning hole

★ Commonly used features.